

---

# HOW TO ATTACH YOUR ARM PADS

---

## Step 1

Hold Arm Pad with zipper toward front of chair arm. The top side will be facing down for the moment.



## Step 2

Engage zipper and close 1-2 inches.



## Step 3

Rotate Arm Pad around so zipper is underneath arm. Now completely close zipper.

